

Basic Operation Information for Glue guns

IMPORTANT! READ BEFORE USE:

- 1. Insert a suitable glue stick into the back of glue gun. Pull the trigger until the glue stick has firmly entered the heating parts.
- 2. Plug glue gun to a suitable electrical outlet and wait for 5 minutes to heat up.
- 3. Pull the trigger gently to apply the glue stick until glue flows out from nozzle. Release trigger to stop flow of glue.
- 4. Apply pressure for about 30 seconds to complete the bonding.
- 5. Unplug glue gun when finished.
- 6. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid hazard.
- 7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision by a person responsible for their safety.

SAFETY CAUTION:

- 1. DO NOT pull glue sticks out of the gun.
- 2. DO NOT touch the heated nozzle or melted glue. Operating temperature can reach 150-200°C (302-392°F).
- 3. DO NOT use around water.
- 4. DO NOT hold the glue gun upside down.
- 5. Unplug when not in use or when unattended.
- **6.** If accidental contact should occur, do not remove the glue. Immerse the burnt area into cold water immediately.

7. KEEP OUT OF REACH OF CHILDREN.

Warning:



www.zicotech.com